Pengsent OBD 2 GPS tracker quotation				
FM08 Plug and play		Frequency GSM 850/900/1800/1900MHz Backup Battery 3.7V 80mAh Operating voltage 10-40V Location ime Cold start 35:s-808 Hot start 1s Location accuracy 5 meters Operating temperature -20°C-+55°C Dimension 45:40025mm Weight 28g	Geo fence Plug & play None wires install Multiple alarms Movement alarm Voice monitor Vibration Alarm/Sos Alarm/Over speed Alarm/Low Battery Alarm	User manual
4G FM08E Plug and play	et da have Bestander Bestander Steamer	Europe & Asia & Africa 4G LTE: B1/B3/B5/B7/BB/20 3G WCDMA: 850/900/2100MHz 2G: 9001800MHz North America & South America 4G LTE: B2/B4/B12 3G WCDMA: 850/1700/1900MHz Australia & New Zealand 4G LTE: B1/B2/B3/H4/B5/B7/B8/B28/B40 3G WCDMA: 850/900/1900/Hz 2G: 850/900/1900/Hz 2G: 850/900/1900/Hz 2G: 850/900/1900/Hz Dimension 67(L)'50(W)'25(H)mm Weight 65g Input Voltage 12V-24VDC Backup battery 3.7 V 120 mAh50mA standby current at 12 V Power consumption 50mA standby current at 12 V Working temperature -20°C to 55°C Humidity 5%-95% non-concretion Sensor 3D acceleration/movement sensor/ temperature gePS Sensitivity -162dBm	OBD II Plug and Play Real-time position acquiring Vehicle trip history and mileage data Geo-Fence alarm and reporting Vehicle towing / Movement alarm Over-Speed alarm and reporting Remove and disconnect alarm Backup battery low power alarm Car battery low power alarm High temperature alarm Power saving / sleep mode Mileage report	Tracker host User manual
2G 3G4G Diagnostico FM08ABC	Concox Protocol support	GSM/GPRS: 850-900/1800/1900MHz UMTS/HSPA: 800/850/900/2100MHz Dimension 63mm (L) x 48mm (W) x 28mm (H) Weigh 53g Stonge: 2MB FLASH, can store up to 64000 GPS data Data Transmission TCP/UDP/FP/HTTP/SMS/Blaetooth/USB OBD Proto-oci: ISO 11898 ISO 91414- ISO 1422a (KWP2000) ISO 157654 SAE 11939 (Ideay daty) Working (Currency: <150mA@13.8/27.6VDC Max. Currency: <200mA@13.8/27.6VDC Max. Currency: <10mA@13.8/27.6VDC Sensor G-Sensor + 6 axis Gyte Huctooth Version Bluetooth 4.0 (Optional) Frequency Bands 2.4Gbz Work mode Slave	Geo fence Plug & pluy Car Dingnosis Data storage Supplementary Report in Dead zones Trip Vinlega Trip Vind Consumption Driving Behavior Monitoring Alarms Reporting Muit Working Mode Remote Configuration Remote Configuration	User manual